



Technical Data Sheet

DOW™ LLDPE DFDC-7087 NT 7 Linear Low Density Polyethylene Resin

Additive

- Antiblock: 6300 ppm
- Slip: 1500 ppm
- Processing aid: No

Properties

Physical	Nominal Value	Unit (English)	Nominal Value	Unit (SI)	Test Method ¹
Density	0.923	g/cm ³	0.923	g/cm ³	ASTM D792
Base Density ²	0.919	g/cm ³	0.919	g/cm ³	Dow Method
Melt Index (190°C/2.16 kg)	1.0	g/10 min	1.0	g/10 min	ASTM D1238
Films					
Film Thickness - Tested	1	mil	25	µm	Dow Method
Film Puncture Energy	13.0	in-lb	1.47	J	Dow Method
Film Puncture Force	6.00	lbf	26.7	N	Dow Method
Film Puncture Resistance	98.0	ft-lb/in ³	8.11	J/cm ³	Dow Method
Film Toughness					ASTM D882
MD	1320	ft-lb/in ³	109	J/cm ³	
TD	1290	ft-lb/in ³	107	J/cm ³	
Secant Modulus					ASTM D882
1% Secant, MD	31300	psi	216	MPa	
2% Secant, MD	27600	psi	190	MPa	
1% Secant, TD	35700	psi	246	MPa	
2% Secant, TD	29900	psi	206	MPa	
Tensile Strength					ASTM D882
MD : Yield	1700	psi	11.7	MPa	
TD : Yield	1680	psi	11.6	MPa	
MD : Break	5880	psi	40.5	MPa	
TD : Break	4250	psi	29.3	MPa	
Tensile Elongation					ASTM D882
MD : Break	580	%	580	%	
TD : Break	680	%	680	%	

1. ASTM: American Society for Testing and Materials
2. Base density is estimated using the assumption that every 1000 ppm of antiblock in the finished product raises the density of the polymer by 0.0006 g/cm³. Base density is the estimated density of the polymer if it did not contain any antiblock.

These are typical properties only and are not to be construed as specifications. Users should confirm results by their own tests.



Properties (Cont.)

Films	Nominal Value	Unit (English)	Nominal Value	Unit (SI)	Test Method
Dart Drop Impact	95	g	95	g	ASTM D1709A
Elmendorf Tear Strength					ASTM D1922
MD	160	g	160	g	
TD	400	g	400	g	
Thermal					
Vicat Softening Temperature	216	°F	102	°C	ASTM D1525
Melting Temperature (DSC)	252	°F	122	°C	ISO 3146
Optical					
Gloss (45°)	17		17		ASTM D2457
Haze	38.0	%	38.0	%	ASTM D1003
Extrusion Notes					
Fabrication Conditions for Blown Film:					
- Screw Size: 3.5in.; 30:1 ratio L/D - Screw Type: DSB II - Die Gap: 70 mil (1.8 mm) - Melt Temperature: 417°F - Output: 12 lb/hr/in. of die circumference - Die Diameter: 8 in. - Blow-up Ratio: 2.5 to 1 - Screw Speed: 39 rpm - Frost Line Height: 52 in					

Product Stewardship

The Dow Chemical Company and its subsidiaries ("Dow") has a fundamental concern for all who make, distribute, and use its products, and for the environment in which we live. This concern is the basis for our Product Stewardship philosophy by which we assess the safety, health, and environmental information on our products and then take appropriate steps to protect employee and public health and our environment. The success of our Product Stewardship program rests with each and every individual involved with Dow products -from the initial concept and research, to manufacture, use, sale, disposal, and recycle of each product.

Customer Notice

Dow strongly encourages its customers to review both their manufacturing processes and their applications of Dow products from the standpoint of human health and environmental quality to ensure that Dow products are not used in ways for which they are not intended or tested. Dow personnel are available to answer your questions and to provide reasonable technical support. Dow product literature, including safety data sheets, should be consulted prior to use of Dow products. Current safety data sheets are available from Dow.



Medical Applications Policy

NOTICE REGARDING MEDICAL APPLICATION RESTRICTIONS: Dow will not knowingly sell or sample any product or service ("Product") into any commercial or developmental application that is intended for:

- long-term or permanent contact with internal bodily fluids or tissues. "Long-term" is contact which exceeds 72 continuous hours;
- use in cardiac prosthetic devices regardless of the length of time involved ("cardiac prosthetic devices" include, but are not limited to, pacemaker leads and devices, artificial hearts, heart valves, intra-aortic balloons and control systems, and ventricular bypass-assisted devices);
- use as a critical component in medical devices that support or sustain human life; or
- use specifically by pregnant women or in applications designed specifically to promote or interfere with human reproduction.

Dow requests that customers considering use of Dow products in medical applications notify Dow so that appropriate assessments may be conducted. Dow does not endorse or claim suitability of its products for specific medical applications. It is the responsibility of the medical device or pharmaceutical manufacturer to determine that the Dow product is safe, lawful, and technically suitable for the intended use. **DOW MAKES NO WARRANTIES, EXPRESS OR IMPLIED, CONCERNING THE SUITABILITY OF ANY DOW PRODUCT FOR USE IN MEDICAL APPLICATIONS.**

